lightspeed™

800iX

Classroom Audio System

User Manual

CONGRATULATIONS!

Congratulations on your purchase of the 800iX Infrared Wireless Microphone System! This simple, yet powerful technology provides the ability to add the benefits of infrared microphone technology to existing amplifiers or to Lightspeed's popular 880iR and 850iR systems to create up to a four-channel solution for the classroom.

The 800iX is a two-channel receiver that allows the use of up to two additional microphones simultaneously. A standard IR sensor can provide high quality reception in rooms up to 1600 square feet. By connecting additional infrared sensors to the receiver, the coverage area can be expanded to provide optimal reception in varying room sizes and configurations.

The REDMIKE® is a two-channel, rechargeable classroom microphone that is clipped to a lavaliere cord and worn around the neck for teacher use, or it can be used as a standard handheld microphone for students to pass around when speaking.

SAFETY INSTRUCTIONS AND CERTIFICATIONS

CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK
DO NOT REMOVE COVER (OR BACK)
NO USER-SERVICEABLE PARTS INSIDE
REFER SERVICING TO QUALIFIED PERSONNEL

The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure, that may be sufficient magnitude to constitute a risk of electric shock.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

CERTIFICATIONS

Complies with 72/23/EEC Low Voltage Directive and 89/336/EEC Electromagnetic Compatibility Directive. Compliance was demonstrated to the following specifications as listed in the Official Journal of the European Union:

EN 60950: Electrical Safety – A1:1993, A2:1993, A3:1993, A4:1997

EN 55022: RF Emissions, Information Technology Equipment

EN 55024: EMC Immunity Standard

EN 61000-3-2: Harmonics

EN 61000-3-3: Voltage Fluctuation

Lightspeed Technologies launched a formal product recycle program in Europe that complies with the European Union Directive 2002/96/EC on Waste Electrical and Electronic Equipment ("WEEE Directive"). Please visit our website at www.Lightspeed-tek.com for more information.

This product is manufactured using lead-free processes and is free of other materials harmful to the environment. It conforms to the most stringent new European guidelines for consumer products (RoHS).

1. **Read Instructions—**All safety and operation instructions should be read before this Lightspeed product is operated.
2. **Retain Instructions—**The safety and operating instructions should be kept for future reference.
3. **Heed Warnings—**All warnings on this Lightspeed product and in these instructions should be followed.
4. **Follow Instructions—**All operating and other instructions should be followed.
5. **Water and Moisture—**This Lightspeed product should not be used near water.
6. **Heat—**This Lightspeed product should be situated away from heat sources such as radiators, etc.
7. **Power Sources—**This Lightspeed product should be connected to a power supply only of the type described in the operation instructions or as marked on this Lightspeed product.
8. **Power Cord Protection—**Power supply cords should be routed so that they are not likely to be walked upon or pinched by items placed upon or against them.
9. **Object and Liquid Entry—**Care should be taken so that objects do not fall onto and liquids are not spilled into the Lightspeed product.
10. **Damage Requiring Service—**This Lightspeed product should be serviced only by qualified service personnel. The user should not attempt to service this Lightspeed product.
11. **Prevent Electric Shock—**Do not use this polarized plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure.

TABLE OF CONTENTS

800iX CLASSROOM AUDIO SYSTEM

Safety Instructions and Certifications ii
SECTION 1: System Overview 1
System Components 2
Front Panel Controls 3
Rear Panel Controls 4
REDMIKE Controls and Connections 5
Cradle Charger Controls and Connections 6
SECTION 2: Installation 7
Unpacking Your System 8
Location of the Receiver/Amplifier 9
IR Sensor Installation 10
Suspended Ceiling Mount 11
Wall/Solid Ceiling Mount 11
Audio Integration 12
Finalizing Connections 14
Final Check 14
SECTION 3: Initial Set-up, Charging and Additional Features 15
Initial Set-Up of REDMIKE 16
Charging the REDMIKE 17
Using the REDMIKE to Amplify External Audio Equipment 18
SECTION 4: Optional Microphones and Accessories 19
Optional REDMIKE VC Controls and Connections 20
Initial Set-Up of Optional REDMIKE VC 21
Charging the Optional REDMIKE VC 22
Optional LT-71 Controls and Connections 23
Initial Set-Up of Optional LT-71 24
Charging the Optional LT-71 25
Optional HM-70 Controls and Connections 26
Initial Set-Up of Optional HM-70 27
Charging the Optional HM-70 28
Audio Integration for the Optional iR Media Connector 29
Intial Set-Up of Optional iR Media Connector 30
SECTION 5: Troubleshooting, Daily Use and Warranty 31
Troubleshooting Guide 32
Daily Use Instructions 33
Tips on Classroom Audio 34
Warranty Statement 34
System Specifications 35
Individual Components and Optional Accessories 36
User Notes 37

SECTION 1

System Overview

SYSTEM COMPONENTS





800iX Infrared Wireless Microphone Receiver and Power Supply



**REDMIKE®
Classroom Microphone**



**SR-70F Infrared
Sensor**

Sensor Cable

Charging Cradle and Power Supply





**Optional REDMIKE™ VC
Volume Control Microphone**

**Optional LT-71 LightMic
and Charger Cable**



**Optional HM-70
Handheld Microphone
and Charger Cable**

Helpful Hint

Keep ALL packaging materials. If the system must be returned, using the original packing material will be quick, convenient and prevent damage.

FRONT PANEL CONTROLS



1. **POWER Switch/POWER Indicator:** This switch is used to turn the 800iX ON (switch up), or OFF (switch down). When the POWER switch is in the ON position, the POWER light will glow red.
2. **IR Indicators (IR):** These lights will glow red when the corresponding microphone is turned on. This light confirms the 800iX is receiving a steady infrared signal.
3. **AF Indicators (AF):** These lights flash green when audio (voice) from the microphone is detected.
4. **A VOLUME:** Controls the volume level of the teacher microphone that is switched to Channel A. Rotating the knob clockwise increases output level.
5. **B VOLUME:** Controls the volume level of the optional second microphone that is switched to Channel B. Rotating the knob clockwise increases output level.

REAR PANEL CONTROLS



1. **DC POWER:** Plug the 16V power supply into this jack.
2. **CHARGERS:** These jacks can be used to charge the optional LightMic or handheld mic as an alternative to connecting them to the REDMIKE cradle charger.
3. **AUDIO OUTPUT:** This 1/4” unbalanced audio output jack may be connected to a “line in” jack on a mixer/amplifier. This output is a mixed audio of channels A and B.
4. **LEVEL (MIC/LINE):** Changes the audio level output from the audio output jack to “mic” or “line” level.
5. **BALANCED AUDIO OUTPUTS:** Two independent audio outputs that may be connected to a balanced microphone input jack on the mixer/amplifier using a standard XLR microphone cable.
6. **SENSOR INPUT:** The IR sensor cable connects to the sensor input. Connect additional sensors to the 800iX to cover large or odd-shaped classrooms.
7. **SENSOR SHORT:** This LED glows when there is a short in one of the sensor cables.

REDMIKE CONTROLS AND CONNECTIONS



1. **POWER BUTTON:** Press this button to turn the REDMIKE ON, press again to turn it OFF (mute).
2. **POWER/LOW BATTERY INDICATOR:** A BLUE light indicates the REDMIKE is on and fully charged. A RED light indicates a charge is needed.
3. **BATTERY COMPARTMENT:** To access the battery compartment, slide the door downward. The battery should only be replaced by a Lightspeed AA rechargeable sensing battery (part # BA-NH2A27).
4. **YELLOW PROTECTIVE TAB:** Slide the battery compartment door open to remove this disposable protective tab before use. **NOTE:** do not attempt to remove the tab without first opening the compartment door, as it may tear, leaving fragments.
5. **AUDIO/MICROPHONE INPUT:** Use this input to plug in a laptop, MP3 player or other audio source to wirelessly transmit audio to be played through the system. Alternatively, an external microphone can be connected.
6. **CHANNEL SELECT SWITCH (CH A/B):** This switch allows for selection between Channel A or B. If you are using a single microphone, we recommend using Channel A.
7. **CHARGER CONTACTS (+ -):** These contacts interface with the charging tabs in the BC-RMCC cradle charger for daily charging. Simply place the REDMIKE in the charger.

CRADLE CHARGER CONTROLS AND CONNECTIONS



1. **CHARGE INDICATORS:** The light glows RED while the REDMIKE is charging. When fully charged, the light will glow GREEN. A blinking RED light indicates that no battery is sensed, (REDMIKE Yellow Protective Tab may not have been completely removed—*see page 5, item 4.*) A blinking Green LED means a non-Lightspeed battery has been installed (possibly an alkaline battery).
2. **DC POWER PORT:** Connect the DC power cord here.
3. **OPTIONAL CHARGING PORT:** Plug the charging cord for the optional LT-71 or the HM-70 microphones here.

Helpful Hint

International Note: Appropriate power cord and adaptor are provided with all Lightspeed equipment.

SECTION 2

Installation

1. UNPACKING YOUR SYSTEM

Ensure that you have received all of the components of your system.





800iX Infrared Receiver/Amplifier and Power Supply





SR-70F Infrared Sensor and cable



REDMIKE®
Classroom Microphone





Charging Cradle and Power Supply

2. LOCATION OF THE RECEIVER

- Before running wires to the 800iX or plugging in, find a suitable, stable location for the amplifier. Ideally, the teacher should have ready access and an electrical outlet should be within six feet. The best possible location for the 800iX is in a media cabinet with any existing audio/ video equipment.

Best



- A good location would be on any stable bookcase or shelf within 6 feet of an electrical outlet. The optional Lightspeed wall shelf (part #AC-800WB) is specifically designed to support the 800iX.



- **Wires** should be routed back directly to the amplifier, so select a location that is free from obstructions that may make routing wire difficult.
(Example: placing the 800iX near a whiteboard or bulletin board would require the wiring to be run an extra distance in order to reach the amplifier.)



3. IR SENSOR INSTALLATION

Sensor location is very important for optimum performance of the 800iX Classroom Audio System.

- **BEST:** On the ceiling at or near the middle of the classroom.
- **GOOD:** High and centered on the long wall.
- **AVOID:** Locations in corners, on walls at heights lower than 7 feet, or in places where the line of sight is or could be obstructed.



IR SENSOR INSTALLATION (cont'd)

Suspended Ceiling Mount



1. **Lift** the ceiling tile nearest the grid rail in your desired sensor location. Guide one side of the C-clip over one edge of the grid rail. Providing firm support to the back of the grid rail with one hand (to prevent bending), firmly and carefully snap the second side of the C-clip over the edge of the rail.
2. **Uncoil** sensor wire. Connect one end of the sensor cable to the plug on the sensor. Secure wire overhead and route it back to the system.
3. **Connect** the other end of the sensor cable into one of the sensor inputs on the back of the system.

Wall/Solid Ceiling Mount



1. **Screw** the plastic mounting strip to a place high on the wall or in the middle of the solid ceiling. Mount the strip horizontally as shown above.
2. **Firmly** snap the C-clip on the back of the IR sensor onto the plastic mounting strip with the sensor plug hanging down (if a wall mount) or toward the receiver location (if ceiling mount).
3. **Uncoil** the sensor wire. Screw one end of the sensor cable to the plug on the sensor. Route the wire back to the system, securing it along the way.
4. **Connect** the other end of the sensor cable to one of the sensor inputs on the back of the system.

Helpful Hint

Use conduit to protect wires.

- **Conduit** is the best means to keep the wires/ cables out of sight and safe from wear. (Conduit is not included.)



4. CONNECTION TO THE AMPLIFIER

1. Ensure the power switch is in the “OFF” position and all front panel volume controls are turned fully counter-clockwise.

2. Locate the 1/4”– 1/4” mono cable.

3. Connect the cable from the 1/4” audio output jack on the 800iX to the input jack on the 880iR, 850iR, or an existing amplifier.



5. AUDIO INTEGRATION

800iX BLOCK DIAGRAM



6. FINALIZING CONNECTIONS

1. Ensure the power switch is in the “OFF” position and all front panel volume controls are turned fully counter-clockwise.



2. Ensure sensor cable is attached securely.



3. Connect DC end of power supply to the black power jack labeled “DC POWER.”

4. Connect the black AC power cable from the power supply to a wall outlet.

FINAL CHECK

1. Ensure all cables are appropriately routed out of walking paths and work areas to prevent safety hazards to individuals in the room.

2. The amplifier packing material should be kept for warranty shipping purposes.

3. Proceed to initial set-up to test system performance.

Leave microphones charging so they are ready for use.
Microphones will need to be charged on a daily basis.

SECTION 3

Initial Set-up, Charging and Additional Features

INITIAL SET-UP OF REDMIKE

1. Turn the 800iX power switch to the ON position. The RED LED on the switch will glow.



2. Turn on the REDMIKE. The RED IR LED on the 800iX will light to indicate a signal is being received.





3. Slip the REDMIKE with lanyard around the neck and position the top of the microphone just below the collarbone. **NOTE:** Positioning of the REDMIKE is critical for proper volume adjustment.

4. While speaking in a normal voice slowly increase the volume of the corresponding channel on the 800iX until your voice is barely audible. **REMEMBER:** This equipment supplements the user's voice so they are able to speak in a conversational tone. Having the volume set too high will result in feedback and listener fatigue.

5. If a second REDMIKE was purchased, repeat steps 2-4.

NOTE: Each REDMIKE has its channel pre-set to either A or B, as indicated on the back of the Mic.



CHARGING THE REDMIKE

1. **Plug** power cord into the cradle charger and then plug the AC end into an electrical outlet.



2. **Ensure** that the REDMIKE is turned OFF.



3. **Place** the REDMIKE into the cradle. The LED on the cradle will glow RED indicating charging has started. When the REDMIKE is fully charged the LED on the cradle charger will change to GREEN.



Helpful Hint

- **REDMIKE incorporates alkaline protection into the microphone design. Replacement AA NiMH batteries may only be purchased through Lightspeed Technologies (part # BA-NH2A27).**
- **A blinking LED indicates a charging error. Be sure to use a Lightspeed rechargeable sensing battery.**

USING THE REDMIKE TO AMPLIFY EXTERNAL AUDIO EQUIPMENT

The REDMIKE includes a 3.5mm audio input jack to connect to an audio source like a laptop or MP3 player. The REDMIKE will transmit the audio signal to be played through the system.

1. **If** your system includes two REDMIKEs, use the student microphone (already set to Channel B). **NOTE:** This feature works on both channels but we recommend using Channel B so the teacher's volume on the CH A does not have to be adjusted. **REMEMBER:** It's easy to determine which REDMIKE is set to Channel B by speaking into the mic and watching which set of LED's glow on the front panel of the 800iX.



2. **Plug** your laptop, MP3 player or other audio source into the input on the REDMIKE labeled "INPUT" using a 3.5mm patch cable.



3. **Adjust** the volume of the selected mic channel to achieve desired loudness.

Helpful Hint

The optional LT-71 can also amplify external audio. Simply plug the 3.5mm patch cable from the audio source into the input labeled "AUX IN" and adjust the volume of the source to the desired sound level.



SECTION 4

Optional Microphones and Accessories

OPTIONAL REDMIKE VC (Volume Control) CONTROLS & CONNECTIONS



1. **POWER BUTTON:** Press this button to turn the REDMIKE VC ON, press again to turn it OFF (mute).
2. **POWER/LOW BATTERY INDICATOR:** A BLUE light indicates the REDMIKE VC is on and fully charged. A RED light indicates a charge is needed.
3. **BATTERY COMPARTMENT:** To access the battery compartment, slide the door downward. The battery should only be replaced by a Lightspeed AA rechargeable sensing battery (part # BA-NH2A27).
4. **YELLOW PROTECTIVE TAB:** Slide the battery compartment door open to remove this disposable protective tab before use.
5. **AUDIO/MICROPHONE INPUT:** Use this input to plug in a laptop, MP3 player or other audio source to wirelessly transmit audio to be played through the system. Alternatively, an external microphone can be connected.
6. **CHANNEL SELECT SWITCH (CH A/B):** This switch allows for selection between Channel A or B. If you are using a single microphone, we recommend using Channel A.
7. **VOLUME CONTROLS (UP - DOWN):** Adjusts microphone volume by pressing the up or down arrow buttons on the back of the REDMIKE VC.
8. **CHARGER CONTACTS (+ -):** These contacts interface with the charging tabs in the BC-RMCC cradle charger for daily charging. Simply place the REDMIKE VC in the charger.

INITIAL SET-UP OF OPTIONAL REDMIKE VC

1. **Turn** the 800iX power switch to the ON position. The RED LED on the switch will glow.



2. **Turn** on the REDMIKE VC. The RED IR LED on the 800iX will light to indicate a signal is being received.





3. **Slip** the REDMIKE VC with lanyard around the neck and position the top of the microphone just below the collarbone. **NOTE:** Positioning of the REDMIKE VC is critical for proper volume adjustment.

4. **While** speaking in a normal voice slowly increase the volume of the corresponding channel on the 800iX until your voice is barely audible. **REMEMBER:** This equipment supplements the user's voice so they are able to speak in a conversational tone. Having the volume set too high will result in feedback and listener fatigue.
NOTE: A nominal volume level must be set on the 800iX before adjusting controls on the REDMIKE VC.

5. **The** teacher can now use the controls on the REDMIKE VC to adjust the volume level from anywhere in the room. The microphone volume control has 4 steps up and 4 steps down from the mid point (9 levels total).



Helpful Hint



NOTE: Each REDMIKE VC has its channel pre-set to either A or B, as indicated on the back of the Mic.

CHARGING THE OPTIONAL REDMIKE VC

1. **Plug** power cord into the cradle charger and then plug the AC end into an electrical outlet.



2. **Ensure** that the REDMIKE VC is turned OFF.



3. **Place** the REDMIKE VC into the cradle. The LED on the cradle will glow RED indicating charging has started. When the REDMIKE VC is fully charged the LED on the cradle charger will change to GREEN.



Helpful Hint

- **REDMIKE VC incorporates alkaline protection into the microphone design. Replacement AA NiMH batteries may only be purchased through Lightspeed Technologies (part # BA-NH2A27).**
- **A blinking LED indicates a charging or sensing error (see page 7.) Be sure to use a Lightspeed rechargeable sensing battery.**

OPTIONAL LT-71 CONTROLS & CONNECTIONS



1. **ON/OFF/MUTE Switch:** This switch turns LT-71 ON or OFF (mute).
2. **Channel Select Switch (CH A/B):** This switch allows for selection of Channel A or B. If you are using a single microphone, we recommend using Channel A.
3. **Power/Charge Indicator:** The light glows BLUE when the LT-71 is powered ON, RED when being charged.
4. **External Microphone Input (MIC):** Use the 3.5mm MIC jack for the optional TK-250 headset microphone (part# MC-TK250LTM).
5. **Auxiliary (AUX):** Plug a laptop, MP3 player or other audio source into this jack to wirelessly transmit the audio signal to be played through the system.
6. **Charger Input (CHARGER):** Plug the charging cable from the charger into this jack for daily charging. The LED on the front will glow RED to indicate charging.

INITIAL SET-UP OF OPTIONAL LT-71

1. Turn the 800iX power switch to the ON position. The RED LED on the switch will glow.



2. Turn on the LT-71 and set the operating channel to “B”.





3. Slip the LT-71 with lanyard around the neck and position the top of the microphone just below the collarbone.
NOTE: Positioning of the LT-71 is critical for proper volume adjustment.



4. While speaking in a normal voice, increase the B VOLUME level until your voice is barely audible. **REMEMBER:** This equipment is designed to supplement and distribute the user’s voice so they are able to speak in a conversational tone. Having the volume set too high will result in feedback and listener fatigue.

CHARGING THE OPTIONAL LT-71

1. Ensure that the LT-71 is turned OFF**.**

2. Make sure the cradle charger is plugged into a wall outlet. Connect one end of the charging cable into the jack labeled CHARGER on the side of the LT-71 and plug the other end into the charging jack on the rear of the REDMIKE cradle charger. The LT-71's rechargeable batteries are factory installed. The LED on the front of the LT-71 will glow RED when charging.



3. Leave the LT-71 plugged in overnight (8–10 hrs.) to obtain a full charge.

NOTE: If the system was purchased without a REDMIKE or REDMIKE VC, the LT-71 will utilize the charger jacks on the 800iX. Connect the charging cable to one of the jacks labeled CHARGE on the back of the 800iX and connect the opposite end to the CHARGER jack on the LT-71.



Helpful Hint

- **Microphones can be left in the charger for up to two weeks without degradation to battery life.**
- **A full charge will be attained in 8-10 hours.**
- **Fully charged Lightspeed microphones will last over 7 hours.**

OPTIONAL HM-70 CONTROLS & CONNECTIONS



1. **ON/OFF/MUTE Switch:** This switch turns the unit ON, OFF or MUTE.
2. **Channel Select Switch (CH A/B):** Located in the battery compartment, the switch is set to Channel B at the factory.
3. **Power/Charge Indicator:** The light glows RED when the HM-70 is powered ON, GREEN when charging.
4. **Charger Input (CHARGER):** Plug the charging cable from the charger into this jack for daily charging.
5. **Infrared Emitters:** Avoid covering the emitters as you grip the HM-70 as this could interrupt signal transmission from the microphone.
6. **Volume Gain Adjustment:** Optimum volume level is pre-set at the factory and no adjustment should be necessary.

INITIAL SET-UP OF OPTIONAL HM-70

1. Ensure the 800iX is ON. The RED LED on the power switch will glow.



2. Turn on the HM-70 by sliding the switch to the top position.



3. Grip the barrel in the center section. Avoid covering the infrared emitters circling the base. This could interrupt signal transmission.



4. While speaking in a normal voice, increase the B VOLUME level until your voice is barely audible. **REMEMBER:** This equipment is designed to supplement and distribute the user's voice so they are able to speak in a conversational tone. Having the volume set too high will result in feedback and listener fatigue.

CHARGING THE OPTIONAL HM-70

1. **Ensure** that the HM-70 is turned OFF**.**
2. **Make** sure the cradle charger is plugged into a wall outlet. Connect one end of the charging cable into the jack labeled CHARGER on the side of the HM-70 and plug the other end into the charging jack on the rear of the cradle charger. The HM-70's rechargeable batteries are factory installed. The LED on the front of the Handheld Mic will glow GREEN when charging.



3. **Leave** the HM-70 plugged in overnight (8–10 hrs.) to obtain a full charge. The GREEN light will turn off when fully charged.

NOTE: If the system was purchased without a REDMIKE or REDMIKE VC, the HM-70 will utilize the charger jacks on the back of the 800iX.



Helpful Hint

Do not attempt to charge alkaline batteries. They can overheat and expand, creating a significant hazard and damaging the LT-71 and HM-70. (This is not covered by the warranty.)

OPTIONAL IR MEDIA CONNECTOR AUDIO INTEGRATION

iRMC BLOCK DIAGRAM



The iRMC is designed to integrate with the 800iX and multiple audio sources, allowing other instructional technologies to be clearly heard throughout the classroom.

INITIAL SET-UP: OPTIONAL IR MEDIA CONNECTOR

1. TURN OFF SECOND MICROPHONE

The iR Media Connector uses the same channel (channel B) as the optional second microphone (REDMIKE, LT71, or HM70). As a result, they cannot be used simultaneously. If you have a second microphone, turn it off before transmitting audio from the iRMC.



2. VOLUME ADJUSTMENT

The iR Media Connector volume is preset for most standard audio signals. If you need to turn the volume up or down, follow this procedure:



1. **Adjust** the volume at the computer, television, or other audio source if possible.



2. **If** the audio source does not have a volume control (such as many DVD players) adjust the volume at the iRMC.

3. **If** the first two options do not give optimum volume level, the last place to adjust the volume is the CH. B Volume on the 800iX.

Helpful Hint

If you adjust the CH B volume on the classroom audio system, you will also be changing the volume for your second microphone. Return the CH B volume knob to the original position before turning the second microphone back on.

SECTION 4

Troubleshooting, Daily Use and Warranty

TROUBLESHOOTING GUIDE

Note: Most problems are directly related to low battery power. Please run through the "Battery Check" items first. For remaining troubleshooting, use known good, fully-charged batteries.

Battery Check

- **Confirm** batteries are charged each night.
- **Confirm** proper batteries are used. The REDMIKE requires the Lightspeed BA-NH2A27 rechargeable sensing battery for proper charging. The LT-71 & HM-70 require NiMH AA rechargeable batteries.
- **Make** sure the microphones are turned off while charging so a full charge is attained. Full charge will last eight hours.
- **Inspect** the battery contacts. Clean and adjust if necessary.

Hearing Static

- **Ensure** sensor is in optimum location (refer to sensor placement in manual). A single sensor will cover a 1600 sq. ft. enclosed classroom.
- **Ensure** that no other REDMIKE/LT71/ HM70 is operating on the same channel.
- **If** the optional iR media connection is in use, set the microphone to Channel A.

Low Volume or Feedback

- **Ensure** microphone is positioned appropriately, just below the collar bone.
- **Check** volume level on the amplifier. If the volume is too high, feedback will occur. Adjust accordingly.
- **Adjust** the volume level on the back of the optional REDMIKE VC.

No Sound From Speaker

- **Turn** the 820iR on. Confirm that the POWER light located on the front panel switch is on.
- **Confirm** signal is being received at the 820iR. The IR signal light will be RED indicating a signal is being received.
- **Confirm** that REDMIKE is turned on. There will be a BLUE LED on the microphone to indicate it is powered on.

If you review these instructions and still have questions, write down the serial number and model number of your system and call Lightspeed Technical Services at 800.732.8999, 5 a.m. – 5 p.m., PST.

DAILY USE INSTRUCTIONS

1. TURN ON THE 800iX

Ensure the power is switched on.

2. POSITION THE REDMIKE



Remove the REDMIKE from the charging cradle and place it around your neck. Adjust the neck strap so the top of the microphone rests just below your collarbone.



3. TURN ON THE REDMIKE

Turn the microphone ON using the ON/ OFF switch on the side of the REDMIKE and speak normally.



4. CHARGE BATTERIES

Place the REDMIKE back into the charging cradle to recharge at the end of the day.



TIPS ON CLASSROOM AUDIO

1	**Speak** in a natural voice. A normal conversational speech levelwill provide an adequate signal. It is not necessary to increase the intensity of your voice—the audio system provides adequate amplification (approximately 5 – 10 dB) above ambient room noises.
2	**Avoid** wearing jewelry that may rub or bump against the microphone.
3	**Turn** the REDMIKE off during private conversations with a student, parent, or other classroom visitor. You can also cover the LED lens on top of the REDMIKE to block the signal.
4	**Recharge** batteries each night. When recharged nightly, operating time (actual usage) for the transmitters will last through a typical school day.

Five-year Limited Warranty

Lightspeed Infrared Audio Systems and optional accessories are warranted against malfunction due to defect in materials and workmanship for a period of five (5) years from date of purchase. System components will be repaired or replaced at Lightspeed's option. Rechargeable batteries and connecting cables are guaranteed for one (1) year. Warranty does not extend to finish, appearance, or malfunctions due to abuse or misuse. Repairs performed by other than Lightspeed Technologies will void this warranty.

For warranty service, including return shipping labels, please contact Lightspeed's Service Department at 800.732.8999 / service@lightspeed-tek.com.

1. Warranty on infrared microphones is FIVE (5) YEARS.
2. Warranty on Lightspeed rechargeable batteries, all external cables and wires provided by Lightspeed is one (1) year.
3. Prepaid shipping labels are provided by Lightspeed factory or an authorized warranty service center for warranty repairs.
4. Warranty does not extend to finish, appearance items, or malfunctions due to abuse or operation other than specified conditions, nor does it extend to incidental or consequential damages. Repair by other than Lightspeed or its authorized service agencies will void this guarantee. Information on authorized service agencies is available from Lightspeed Technologies, Inc.

Our Service Department (800.732.8999, 5 a.m. – 5 p.m., PST) will handle all your repair/replacement needs.

SYSTEM SPECIFICATIONS

OVERALL SPECIFICATIONS

Standard Carrier Frequencies (IR)	2.06/2.54 MHz
Alternative Carrier Frequencies (IR)	3.2/3.7 MHz
Frequency Stability	± 3%
Signal-to-Noise Ratio	> 73 dB
Dynamic Range	> 73 dB
Frequency Response	100 Hz - 10 KHz

RECEIVER SPECIFICATIONS

Receiver Type	Superheterodyne
Receiver Sensitivity	6 µV for 60 dB S/N
Image and Spurious Rejection	> 70 dB
Dimensions (W x D x H)	17.3” x 8.5” x 1.75”
Weight	5.2 lbs.

TRANSMITTER SPECIFICATIONS

REDMIKE and REDMIKE VC

Audio Distortion	< 1 %
Built-in Microphone	Unidirectional Electret
Battery Power (1-year warranty)	1 AA NiMH Rechargeable Sensing Battery
Audio Input	3.5 mm
Dimensions (W x D x H)	0.9” x 1.0” x 3.5”
Weight	2.1 oz.

LT-71 LightMic

Audio Distortion	< 1 %
Built-in Microphone	Unidirectional Electret
Battery Power (1-year warranty)	2 AA NiMH Rechargeable
Audio Inputs	Mic Level 3.5 mm Line Level 3.5 mm
Dimensions (W x D x H)	1.375” x .75” x 4.625”
Weight	3.7 oz.

HM-70 Handheld Microphone

Audio Distortion	< 1 %
Built-in Microphone	Unidirectional Electret
Battery Power (1-year warranty)	2 AA NiMH Rechargeable
Dimensions (W x D x H)	2.25” x 2.25” x 8.75”
Weight	7.36 oz.

IR SENSOR SPECIFICATIONS

Working Range	Up to 1600 square feet per sensor
Cable	50 ft., Plenum-rated
Mounting	Ceiling clip/Wall bracket
Dimensions	4.25” (Diam.) x 2.0” (H)
Weight	4.5 oz.

INDIVIDUAL COMPONENTS & OPTIONAL ACCESSORIES

Part Number	Description
RX-800	Infrared receiver/amplifier/mixer
PS-16V-1.0	Power supply/battery charger for 800iX
IR-SR70F	Infrared sensor with cable and wall or ceiling mounting bracket
CA-PC50F	Plenum sensor cable (50 ft.)
RMT	REDMIKE classroom microphone w/lavaliere cord and rechargeable AA battery
BA-NH2A27	Lightspeed AA rechargeable sensing battery (for REDMIKE)
AC-LTCB	Lavaliere cord for REDMIKE, LT-71
BC-RMCC	REDMIKE cradle charger
PS-5V-1.0	Cradle charger power supply
Optional Accessories	
LT71	LightMic microphone with lavaliere cord, rechargeable batteries and charging cable
HM70	Handheld microphone with rechargeable batteries and charging cable
MC-TK250LTM	Noise-canceling headset microphone
AC-TCC7	Charging cable for LT-71 and HM-70 microphones
AC-800WB	Wall shelf
CA-RCA6	6’ dual RCA audio cable
CA-RCA24	24’ dual RCA audio cable
CA-MSC3535	3.5mm to 3.5mm stereo audio cable
CA-MMC2535	Audio patch cable (2.5 mm mono to 3.5 mm mono)
SPEAKERS	Contact Lightspeed at 800.732.8999 for speaker information

USER NOTES

	Record your system serial numbers and purchase information. This is helpful when ordering additional components, accessories, and/or warranty service.
Components	**Serial Number**
800iX	
Microphones	
Sensors	
Speakers	
Purchase Information	
Your School/Organization	
District	
Purchase Date	
Invoice	

USER NOTES

USER NOTES

USER NOTES

USER NOTES

lightspeed™

AC-MN800

LIGHTSPEED TECHNOLOGIES
11509 SW HERMAN ROAD / TUALATIN, OR 97062
TOLL FREE: 800.732.8999 / PHONE: 503.684.5538 / FAX: 503.684.3197
LIGHTSPEED-TEK.COM

MN0191US01-1